Service Bureaus

Encompassing everything from companies offering quickturn prototyping to machine shops to injection molding firms, service bureaus play a key role in the manufacturing ecosystem. They produce a wide range of parts, including one-off functional prototypes and low- to mid-volume production runs.







Challenge

Many customers rely on service bureaus to produce parts they can't make internally because they may not have the equipment, capacity or time to do it inhouse. To meet customers' unique, iterative, or low-volume needs, the tooling, complex fixturing, or multiple machining required for traditional manufacturing methods are often impractical due to the associated long lead times and high costs.

Customers also turn to service bureaus as a way to explore new manufacturing technologies before making large-scale investments. Prior to rolling out new manufacturing methods, companies often look to service bureaus for benchmarking and prototyping, so access to innovative production methods is essential to help win bids, attract new customers, and expand accounts.

In cases where custom tooling is needed, shops must produce those tools as quickly and affordably as possible to meet customers' needs, then store and track those tools if replacement or additional parts might be needed in the future.



Solution

Additive manufacturing allows service bureaus to extend the benefits of metal 3D printing - such as tooling-free production, assembly consolidation, and new levels of geometric freedom and part complexity - to their customers. features like overhangs and internal channels

Using binder jetting, service bureaus can create parts directly from a digital CAD file without the need for tooling, allowing them to cost-effectively produce low-volume batches of complex parts, simultaneously produce parts with different geometries without the need for multiple setups, and produce hundreds of highly-complex, near-net-shape parts every day without the constant oversight of a skilled machinist.

By lowering setup and part costs, metal 3D printing can change the part-cost equation for service bureaus, enabling them to win new business, including small or medium jobs that might previously have been "no bid" due to expensive mold-tooling or CNC-setups. The systems also free up CNC capacity for other, more profitable jobs.

For those jobs where tooling is needed, 3D printing in-house can reduce both the lead time and cost to create workholding, jigs, and fixtures to make production workflows more efficient. And since printing is an additive process, increased tool complexity does not lead to increased cost. The end result is more efficient manufacturing and reduced warehousing costs as companies store tools as digital files rather than physical objects.

Service Bureaus Examples





These bolt replacement grippers are installed into a robot arm to pick and place thousands of bolts per day on an assembly line. While they look simple to machine, the intricate teeth require fine detail machining and multiple tool switches to complete.

On-demand production with the binder jet 3D printing on the Shop System enables a Take One Make One (TOMO®) digital inventory strategy at Azoth, a contract manufacturer in Ann Arbor, Michigan, that specializes in delivering precision metal components. With the capability to produce 1400 end-use parts per day, binder jetting is the more cost-effective production method for these grippers, delivering parts with a 10-day turnaround compared to an eight-week lead time.

The 17-4PH stainless steel components are heat treated to H900 to replace the traditionally machined tool steel parts.

[B] Gaming Equipment Fork Mechanism

Traditionally a seven-piece assembly, each stamped or machined and screwed together, a customer of AmPd Labs in Houston, Texas was looking to capitalize on the benefits of consolidation for this fork mechanism. Combining components is one of the best ways to be cost effective with benefits including derisked supply chains, stocking fewer part skews, eliminating lost components, reducing assembly time, and improving performance by minimizing potential points of failure of an assembled product.

The consolidated assembly was binder jet 3D printed in 17-4 PH stainless steel on the Shop System as one piece. Eliminating the time and labor needed for an assembly process, as well as on-demand production eased supply chain logistics. Live Sinter™ software played a key role in the success of keeping the long, cylindrical part in tolerance with its sintering simulation and compensation analysis.

Service Bureaus Examples





Essential for production, jigs and fixtures needed for a variety of products require expensive tooling and come with long lead times that can delay getting finished products to market. The high demand of these mechanical devices overloads the dedicated in-house machine shop at Jade Groupe's manufacturing facility, resulting in high lead times, affecting production efficiency.

Digital production allows the team to quickly create parts to solve its specific production problems without disrupting CNC production or ordering an off-the-shelf part. Fixtures are produced with binder jetting on the Desktop Metal Shop System without the cost or lead time of traditional tooling.

Redesigned for binder jetting, the 3D printed fixtures are 42% lighter than the original component while creating a design optimized for performance in a more efficient workflow.

Other tooling prints have created sacrificial tools for a polishing operation that reduce costs 20% compared to traditional production or adapters to standardize process steps while making them more ergonomic for employees.



[D] Custom Bolt and Connecting Bar

These custom-designed components were needed when needed when no off-the-shelf solution would work for very specific applications.

Due to the high cost of hard tooling, While most bolts are manufactured in quantities of millions due to the high cost of hard tooling, the custom bolt pictured at top was only needed in a quantity of a few tens of thousands. Similarly, the connector bar pictured below the bolt is a custom design used to attach two rotating components in a machine design.

Utilizing 3D printing on the Shop System™, both are produced without tooling, leading to a dramatically reduced per-part cost.

Because no tooling is used, the designer is free to change the length, thread profile, pitch, and other characteristics of the bolt on demand by simply altering parameters in the CAD file and starting a new print, providing the customer increased flexibility without increasing set up demands of their service bureau.

By printing the connecting bar the number of secondary processing steps could be reduced, as the part was fully functional right out of the furnace, eliminating production steps leading to further cost and lead time savings. This bar also incorporates a light weighting feature that improves performance but couldn't be cost-justified with traditional manufacturing methods.

Service Bureaus Examples





[E] Bearing Inner Race

This inner race of a custom bearing was taken to a service bureau to take advantage of a technology the part designer didn't have in house - binder jetting. The metal 3D printing process can create parts with more complex features at no additional cost.

The internal square fixturing features in this part cannot be machined and would require a collapsible core to be metal injection molded, adding significant cost to the tooling. Similarly, the divots in the bearing race would require surfacing with a ball mill, an expensive and time-consuming machining process.

This part is easily printable on the Shop System[™], allowing for production of an optimized design without increased part cost for the complexity. And since no tooling is involved, the design can easily be updated for different sized bearings and printing can start in a few hours, as opposed to a days-long turnaround for custom tooling and setups.

[F] Bearing Housing

This housing is used to hold pressed-fit bearings in place in a machine. This part needed to be produced quickly out of steel. Using the Shop System[™], the required 100 housings were printed in just four days and were ready for assembly in less than a week, requiring almost no operator labor.

Printing this housing with binder jetting technology dramatically reduced the manufacturing lead time compared to traditional methods, allowing the service bureau customer to meet their tight deadline and avoid expensive custom tooling setups.

Additive Manufacturing 2.0

Metal | Polymer | Ceramic | Composite | Wood

Printer platforms



Desktop Health



6 FIGUR

Materials





Applications and more



©aero**sint**

Desktop Labs

DESKTOPMETAL.COM

Desktop Metal (NYSE:DM) is driving Additive Manufacturing 2.0, a new era of on-demand, digital mass production of industrial, medical, and consumer products. Our innovative 3D printers, materials, and software deliver the speed, cost, and part quality required for this transformation. We're the original inventors and world leaders of the 3D printing methods we believe will empower this shift, binder jetting and digital light processing. Today, our systems print metal, polymer, sand and other ceramics, as well as foam and recycled wood. Manufacturers use our technology worldwide to save time and money, reduce waste, increase flexibility, and produce designs that solve the world's toughest problems and enable once-impossible innovations. Learn more about Desktop Metal and our #TeamDM brands at DesktopMetal.com